

Water Care

On Fill Up:

Lakewater:

4 pucks in basket

2 capfulls shock

Well Water:

3 pucks in basket

1 1/2 capfulls shock

City Water:

2 pucks in basket

1 capfull shock

Regular Maintenance:

Bromine:

1 puck at all times (or more is test strip reading is low)

Shock:

1 TSP/person end of day

Test Strip:

Balance PH first (up or down)

Alkalinity should follow (if not, start with 1 TSP Baking Soda)

When PH & Alkalinity are balanced, then Bromine reading will be accurate.

Spa Perfect:

Add 1oz every 6 - 7 days (not at same time as Bromine & Shock)

Defoamer:

Very little required when foam appears.